

2024

SVA-SLIP

User Guide

Prepared for: **FLORIDA DEPARTMENT OF ENVIRONMENTAL
PROTECTION**
OFFICE OF RESILIENCE AND COASTAL PROTECTION

Prepared By  **SEAMGEN**

Revision History

Version #	Date	Status	Author/Modified By	Revision Description
1.0	12/09/2024	Approved	Katie Bielawiec, Trevor Keller	Original version.
2.0	02/20/2025	Approved	Jennifer Ventura	Updated email verbiage in Appendix A to match production emails.
3.0	07/15/2025	Approved	Jennifer Ventura	Updated 'A.11 SLIP Study Published for 30 days' email verbiage in Appendix A to match the production email revised on 06/26/2025.
3.1	12/29/2025	Approved	James Cichon	Updated SLIP help. Moving point to intersect SLIP boundary if project area touches it. Updated create an account information for contractors.

Table of Contents

1	Introduction	6
1.1	URL.....	6
1.2	System Description.....	6
2	Login & Account.....	7
2.1	Create Account	7
2.2	Join an Organization.....	9
2.3	Request New Organization.....	11
2.4	Login	13
2.5	Your Organization	13
2.6	Notifications.....	16
2.7	Map Data Layer Disclaimer.....	17
3	SVA Map Viewer	18
3.1	General Layout	18
3.1.1	Top Bar	18
3.1.2	Side Bar.....	20
3.1.3	Map Controls.....	21
3.2	Layers.....	21
3.2.1	Selecting Active Layers	21
3.2.2	Modeling Layers.....	24
3.3	Item Details	26
3.4	Location Filtering	26
3.5	Views.....	28
3.5.1	Save View	28
3.5.2	Select View	29
3.5.3	Edit/Share View.....	31
3.5.4	Delete View.....	32
3.6	Base Map.....	33
3.7	Legend	34
3.8	Export Data	35

4 Projects.....	37
4.1 General Layout	37
4.2 Create New Project.....	39
4.3 View Project Details.....	41
4.4 Edit Project Details	41
4.5 Delete Project.....	42
4.6 Generate SLIP Report	43
4.7 Initiate New Grant Application.....	45
4.8 Create Project from Critical Asset.....	46
5 Admin.....	49
5.1 Organization Admin	49
5.1.1 All Organizations.....	49
5.1.1.1 Approve Org Access	49
5.1.1.2 Organization Users	51
5.1.2 Eligible Entity Organizations	51
5.1.2.1 View Contractor Orgs	51
5.1.2.2 Invite Org	53
5.1.2.3 Remove Org	55
5.1.3 Contractor Organizations	56
5.1.3.1 View Eligible Entity Orgs.....	56
5.1.3.2 Request Access	57
5.1.3.3 Remove Org	59
Appendix A: Email Notifications	61
A.1 Organization Access Requested (Employee).....	61
A.2 Organization Access Approved.....	61
A.3 Organization Access Denied	61
A.4 Organization Access Requested (Contractor Relationship)	62
A.5 Organization Access Approved (Contractor Relationship)	62
A.6 Organization Access Denied (Contractor Relationship).....	62
A.7 Organization Access Approved (New Organization)	63
A.8 Organization Access Denied (New Organization)	63

A.9 SLIP Study Approved.....	63
A.10 SLIP Study Denied	64
A.11 SLIP Study Published for 30 Days.....	64
A.12 Invitation to Join Organization	65
A.13 Contractor Denied Invitation Request.....	65
A.14 Contractor Approved Invitation Request.....	65

1 Introduction

1.1 URL

Go to <https://floridadep-slip.org> to access the SVA-SLIP Tool. Users will be redirected to the site below.

Or use the direct link: <https://prodapps.dep.state.fl.us/orcp-sva>

1.2 System Description

The Florida Department of Environmental Protection Statewide Vulnerability Assessment evaluates environmental risks across Florida. It examines the impacts of climate change, sea-level rise, extreme weather, and human activities on natural resources, infrastructure, and communities. By collecting and analyzing data on coastal erosion, flooding, water quality, and ecosystem health, the assessment uses advanced modeling to project future scenarios and identify vulnerable areas. This information guides policy decisions, resource management, and actions to enhance resilience, protect public health, and ensure sustainability. The goal is to safeguard Florida's environment and improve its response to environmental challenges.

2 Login & Account

2.1 Create Account

From any page, if you are logged out, you can use the “Create Account” button to be taken to the Florida DEP Business Portal to register.



Figure 1: SVA Top Navigation Bar (Logged Out)

Once you have created a Florida DEP Business Portal account and signed in, you will be prompted to find your organization.

This can be skipped if you are not part of an eligible entity organization or contractor organization. Public users should not attempt to join an organization.




Figure 2: Organization Affiliation Modal

2.2 Join an Organization

County/City employees should join their eligible county or city organization. **Contractors should join (or create) a contractor organization. They should not join an eligible entity organization.**

Contractors can be associated with eligible entities by following instructions starting on page 51.

Once you have joined your organization (see **2.2 Join an Organization**) or skipped this step, you will be logged in and ready to use the SVA system.

When creating an account or adding yourself to an organization, you will be prompted to search for your organization by Organization Name or ZIP Code.

NOTE: At any point in this flow, you may click "I don't want to join an organization right now" to exit the flow and be taken back to the SVA Map Viewer.

Organization Details

Next, let's find or create your organization.

Zip Code Organization Name

Organization Name	Organization Type
<input type="radio"/> AcmeCorp Planning, Inc. (ACMEP)	Contractor
<input type="radio"/> AcmeCorp Development, LLC (ACMED)	Contractor
<input type="radio"/> AcmeCorp Cityworks, Inc. (ACMECI)	Contractor
<input type="radio"/> AcmeCorp Builders Association (ACMEB)	Contractor
<input type="radio"/> AcmeCorp Contractors, LLC (ACMECo)	Contractor

Can't find your organization? [Request New Organization](#)

[Back](#) [Continue](#)

[I don't want to join an organization right now](#)

Figure 3: Organization Details

After entering a search term, you will be presented with a list of organizations in the system.

Organization Details

Next, let's find or create your organization.

Zip Code: 33101 Organization Name: AcmeCorp

Organization Name	Organization Type
AcmeCorp Planning, Inc. (ACMEP)	Contractor
AcmeCorp Development, LLC (ACMED)	Contractor
AcmeCorp Cityworks, Inc. (ACMECI)	Contractor
AcmeCorp Builders Association (ACMEB)	Contractor
AcmeCorp Contractors, LLC (ACMECo)	Contractor

Can't find your organization? [Request New Organization](#)

[Back](#) [Continue](#)

[I don't want to join an organization right now](#)

Figure 4: Organization Details (Filled)

Select your organization from the list, then click “Continue”.

If you do not see your organization, click “Request New Organization” to begin entering your organization details so it can be added to the system (see **2.3 Request New Organization**).

Next, select your role within your organization from the “Your Role” dropdown menu and click “Continue”.

The available roles to select are:

Administrator: Provides advanced access to the organization, with permissions to manage organization users, views, and projects

Employee: Provides basic access to the organization, with additional permissions that can be provided by the organization’s primary admin

Organization Details

Now tell us your role with the organization you selected.

Organization Details

Organization Name	Organization Type
AcmeCorp Planning, Inc. (ACMEP)	Contractor

Your Role

Required

Back Continue

[I don't want to join an organization right now](#)

Figure 5: Choose Role

Pending approval from your organization's administrator, you have successfully added yourself to your organization.

2.3 Request New Organization

Upon clicking “Request New Organization” during the **Join an Organization** flow, you will be prompted to add the details of your organization so it can be added to the system.

The required organization details include:

Organization Full Name: The full written name of your organization

Organization Short Name: An optional abbreviated name of your organization (up to 6 characters)

Organization Type: Eligible Entity or Contractor

Organization Details

Next, let's find or create your organization.

Request New Organization

Organization Full Name Organization Short Name
Required Optional

Organization Type

Required

[I don't want to join an organization right now](#)

Figure 6: Request New Organization

Enter the details for your organization, select your role, then click “Continue.”

You will be taken to the Organization Details screen, where you must select your role within your organization from the “Your Role” dropdown menu and click “Continue”.

The available roles to select are:

Administrator: Provides advanced access to the organization, with permissions to manage organization users, views, and projects.

Employee: Provides basic access to the organization, with additional permissions that can be provided by the organization's primary admin.

Figure 7: Request New Organization - Choose Role

Your organization info will be sent to the Florida DEP for review. Once it is approved, you will be notified via the notifications panel and by email (see Appendix A.7) that your organization has been successfully created and you have been added to it.

2.4 Login

From any page, if you are logged out, you can use the “Login” button to be taken to the Florida DEP login portal.



Figure 8: SVA Top Navigation Bar (Logged Out)

Once you have completed login through the Florida DEP Business Portal and your SVA account info is found, you will be granted access to the platform.

2.5 Your Organization

From any page, if you are logged in, you can use the Account icon button to bring up the account menu.




Figure 9: Account Menu

Click the “Organization Settings” menu item to be taken to the Organization Settings page.




Figure 10: Your Organization

On this page, you can leave your current organization or request to join an organization (if you are not currently part of one).

2.6 Notifications

From any page, if you are logged in, you can use the Notifications icon button on the top bar to bring up the Notifications panel.




Figure 11: Notifications

From this panel, you can see all of your notifications.

Some notifications have a “View Details” button that allows you to view more details.

To delete a notification, click the Delete icon button on the respective notification. You will be presented with a confirmation dialog. Click “Delete” to permanently remove the notification.




Figure 12: Delete Notification

2.7 Map Data Layer Disclaimer

Upon first opening the SVA Map Viewer, you will be prompted with a disclaimer regarding the sourcing of map data for the system.




Figure 13: Map Data Layer Disclaimer

Selecting the option “Don’t show this again” will prevent this disclaimer from being shown on future logins. Clicking “Okay” without selecting that option will allow this disclaimer to be displayed upon each login to the system.

3 SVA Map Viewer

3.1 General Layout

3.1.1 Top Bar

Once you are logged into the system, you will be presented with a consistent top navigation bar, which allows you to access various app functions.




Figure 14: SVA Top Navigation Bar (Logged In)

The two main tabs, SVA Map Viewer and Projects (see [4 - Projects](#)), allow you to switch between the core sections of the SVA system.

For administrator users, there will be an additional Admin tab to access related administrative content (see [5 - Admin](#)).

The two icon buttons on the right, Notifications (see [2.6 Notifications](#)) and Account (see [2.5 Your Organization](#)) allow you to access their respective features.

The dark-gray lower section of the navigation bar provides additional functionality specific to the SVA Map Viewer tab:

Current View: Shows the currently loaded view (see [3.5 Views](#))

Recenter View: Resets the bounds of the viewport to focus on the currently loaded view

Zoom to Fit: Sets the bounds of the viewport to fit all currently loaded map data

Clear View: Clears all selected layers and filters, and deselects the current view, if there is one

Show Boundary: Shows the bounds of the currently loaded view

Export Data: Allows for the export of map data in various formats (see [3.9 Export Data](#))

Save View: Allows you to save the currently loaded map features as a view (see [3.5.1 Save View](#))

3.1.2 Side Bar

On the SVA Map Viewer tab, you will be presented with a side navigation bar that allows you to interact with the various features of the map viewer:

See All Views: Shows a list of all available views (see [3.5.2 Select View](#))

Layers: Opens the Layers panel, which allows the toggling of various data layers and interactive modeling layers (see [3.2 Layers](#))

Base Map: Allows you to change the base map between various defaults (see [3.7 Base Map](#))

Legend: Shows list of all loaded map items and what they represent (see [3.8 Legend](#))

Location Filters: Allows for the filtering of data to specific geographical regions (see [3.4 Location Filtering](#))

Collapse: Collapses the side navigation bar into a more compact format




Figure 15: SVA Map Viewer Side Navigation Bar

3.1.3 Map Controls

On both the SVA Map Viewer and Projects tabs, there are controls that allow you to navigate the map and access some additional system functions:

Zoom In / Zoom Out: Shows a list of all available views (see [3.5.2 Select View](#))

Search: Allows you to search for a specific address or location and center the map on it




Figure 16: Map Viewer Controls

3.2 Layers

3.2.1 Selecting Active Layers

On the SVA Map Viewer tab, you can use the left-side navigation bar to open the Layers panel. This will show a list of all available layers for display.




Figure 17: Layers Panel

You can expand certain layer groups to show individual layers within those groups.




Figure 18: Layers Panel (Critical Infrastructure Expanded)

Turning on a layer will display its data on the map. Selecting a layer (by clicking the layer row, not the switch on the row) will show a details panel for the selected layer.

Here are the layers available for display:

- Topography Layers
 - Digital Elevation Models (USGS)
 - Elevation Certificates
- Land Use & Other Features
 - SLIP Reports
- Critical Asset Layers
 - Critical Infrastructure
 - Communications Facilities
 - Disaster Debris Management Sites
 - Drinking Water Facilities
 - Electric Production and Supply Facilities – PT
 - Solid and Hazardous Waste Facilities
 - Solid and Hazardous Waste Facilities – SQG
 - Solid and Hazardous Waste Facilities – TSD
 - Solid and Hazardous Waste Facilities – SB
 - Stormwater Treatment Facilities and Pump Stations – PT
 - Wastewater Treatment Facilities and Lift Stations
 - Water Utility Conveyance Systems
 - Electric Production and Supply Facilities – PL
 - Stormwater Treatment Facilities and Pump Stations – PL
 - Stormwater Treatment Facilities and Pump Stations – PG
 - Military Installations
 - Critical Community and Emergency Facilities
 - Affordable Public Housing
 - Colleges and Universities
 - Community Centers
 - Correctional Facilities
 - Disaster Recovery Centers
 - Emergency Medical Service Facilities
 - Emergency Operation Centers
 - Fire Stations
 - Health Care Facilities
 - Hospitals
 - Law Enforcement Facilities
 - Local Government Facilities
 - Logistical Staging Areas
 - Risk Shelter Inventory
 - Schools
 - State Government Facilities

- Natural, Cultural, and Historical Resources
 - Historical and Cultural Assets – PT
 - Historical and Cultural Assets – PL
 - Shorelines
 - Surface Waters – PL
 - Conservation Lands
 - Historical and Cultural Assets – PG
 - Parks
 - Surface Waters – PG
 - Wetlands
- Transportation and Evacuation Routes
 - Airports
 - Bus Terminals
 - Marinas
 - Ports – PT
 - Rail Facilities – PT
 - Railroad Bridges
 - Bridges
 - Major Roadways – FDOT
 - Major Roadways – NTD
 - Ports – PL
 - Rail Facilities – PL
- Locally Provided Assets
 - Locally Provided Assets – PT
 - Locally Provided Assets – PL
 - Locally Provided Assets – PG

3.2.2 Modeling Layers

On the Layers panel, you can find a collection of modeling layers that provide additional visualizations for the State of Florida:

- Sea Level Rise (SLR)
- Areas at Risk from Sea Level Rise
- Flood Zones
- High Tide Flooding
- Wildlife Index
- Wind Zones

Some of these layers have additional options and are described here:

The Sea Level Rise layer allows you to visualize the impact of 0-10 ft of sea level rise across the Florida coast.




Figure 19: Sea Level Rise

The Wind Zones layer allows you to select from four different Risk Categories (I, II, III, and IV) to view wind zones across the state of Florida.




Figure 20: Wind Zones

3.3 Item Details

When a layer is active, you can select any visible data point on the map to view the details panel for that item. This panel will show any relevant metadata and allow you to navigate between overlapping layers.




Figure 21: Item Details Panel

3.4 Location Filtering

On the SVA Map Viewer tab, you can use the left-side navigation bar to open the Location Filters panel. This will show a list of available categories to filter by.




Figure 22: Location Filters Panel

Clicking into one of the categories will show a list of all filters within that category. The map will also show a visual of all the available filters. Filters can be activated by turning it on in the list or clicking its area on the map.




Figure 23: Location Filters Panel (County Boundaries Expanded)

3.5 Views

A view is the named collection of settings for a particular use of the SVA Map viewer. Specifically, when using the map viewer with a view, the view establishes:

- 1) The geographic extent visible in the SVA Map viewer (pan location, zoom level, etc.)
- 2) The map layers selected for inclusion (see **3.2 - Layers**)
- 3) The owner of the view and all users the view has been shared with
- 4) All location filters applied to the map

3.5.1 Save View

At any point, on the SVA Map Viewer tab, you can use the “Save View” button on the upper bar to save the current map viewer configuration as a view.




Figure 24: SVA Top Navigation Bar (Logged In)

If you have already loaded an existing view, you will be asked if you would like to update the existing view or create a new view.




Figure 25: Save View Panel (New View Prompt)

When creating a new view, you will need to enter a name for the view, then you can enter an optional description of the view and share it with any desired users.




Figure 26: Save View Panel

3.5.2 Select View

On the SVA Map Viewer tab, you can use the “See All Views” tab on the left-side navigation bar to open the Views panel. This will show all views that have been created by you or shared with you.




Figure 27: Views Panel

When a view is selected, you can see the extent of the map viewer, as well as, all enabled layers on that view. Here you can also apply the view, share the view, export the view data, or delete the view.




Figure 28: View Details

3.5.3 Edit/Share View

To edit an existing view, start by applying the desired view from the Views menu (see [3.5.2 Select View](#)). Once the view is applied, make any desired edits to the view (selecting/deselecting layers, changing location filters, etc), then use the “Save View” button on the top bar to begin saving your changes.

You will be presented with a panel asking you to decide between saving the changes to your current view or creating a new view. Click the “Save Changes” button to save your edits to the current view.




Figure 29: Save View Panel (New View Prompt)

From the view details panel, you can share the view with any number of users. Once you click the “Share View” button, you will be shown a dialog that allows you to share the view with new users or remove existing users that you have already shared the view with.




Figure 30: Share View

3.5.4 Delete View

From the view details panel for a desired view, you can click the “Delete View” button to begin deleting the view.




Figure 31: View Details

You will be shown a dialog asking you to confirm the deletion. All other users that the view has been shared with will lose access to the view.




Figure 32: Delete View

3.6 Base Map

On the SVA Map Viewer tab, you can use the left-side navigation bar to open the Base Map panel. This will allow you to change the base visual layer of the map viewer.

This is purely a cosmetic change and will not affect the functionality of the map viewer.




Figure 33: Base Map Panel (Imagery)




Figure 34: Base Map Panel (Light Gray Canvas)

3.7 Legend

On the SVA Map Viewer tab, you can use the left-side navigation bar to open the Legend panel. Here you can see a key for all of the visible data layers on the map and what each glyph represents.




Figure 35: Legend Panel

3.8 Export Data

Data for a view can be exported by first applying the desired view from the Views menu (see [3.5.2 Select View](#)). Once the view is applied, use the “Export data” button on the top bar to begin exporting data.

You will be presented with a dialog with information about the export process. By default, map layers will be exported in a set format along with the rest of the map data, but links are provided to download the data in other formats.

Point, polyline, and polygon geometry layers are exported as .GeoJSON files, and raster layers are exported as .PNG files.

Critical Asset layers have more robust export options (Shapefile, Geodatabase, GeoPackage, CSV, etc.), which can be found in links provided during the export process.




Figure 36: Export View Data Modal

Once you click “Export”, the selected view will be compiled into an exportable package and you will be shown the status of each layer group. Once this is complete, you may download the collection of map data.




Figure 37: Export View Data (Confirmation) Modal

4 Projects

4.1 General Layout

Clicking on the **Projects** tab will open up the **Projects** panel, which lists all of the projects you have access to.




Figure 38: Projects Panel

On the **Projects** panel, there are three main controls:

Search Projects: A search bar that lets you search for projects you have access to.

Filter: A dropdown menu to filter which projects you are seeing.

Create New Project: A button that allows you to create a new project.

4.2 Create New Project

From the **Projects** panel, click the “Create New Project” button to open the **Create New Project** panel.




Figure 39: Create New Project Panel

On this panel, select a point on the map where the project will be located. The project location will be shown as a pin on the map:



Once the project location is selected, fill every field on the form to accurately match the project details, then click “Create Project”.

You will be taken to the details of the **Project Details** panel for the newly created project and a notification will be displayed to show that the project was successfully created.

4.3 View Project Details

From the **Projects** panel, click on one of the listed projects to open the **Project Details** panel.




Figure 40: Project Details Panel

On this panel, you can view the details of the selected project and perform various actions on that project, which are all described in the next sections of this document.

4.4 Edit Project Details

From the **Project Details** panel for a selected project, you can click “Edit Project” to open the **Edit Project** panel.

NOTE: The **Edit Project** panel is only available for projects that do NOT yet have a published SLIP Report or an initiated Grant Application.




Figure 41: Edit Project Panel

On this panel, you can edit any of the project details except for “Organization”.

4.5 Delete Project

From the **Project Details** panel for a selected project, you can click “Delete Project” to open a confirmation modal to confirm the deletion.

NOTE: Project deletion is only available for projects that do NOT yet have a published SLIP Report or an initiated Grant Application.




Figure 42a: Delete Project Modal

On the confirmation modal, click the “Delete Project” button to confirm the deletion.

Once the project is successfully deleted, you will be taken back to the Projects panel and a notification will be displayed to show that the project was successfully deleted.

4.6 Generate SLIP Report

From the **Project Details** panel for a selected project, you can click “Generate SLIP Report” to open a confirmation modal to confirm the report creation.

NOTE: *SLIP Reports can only be generated for projects that do NOT yet have a published SLIP Report. Also, the project must be in the “area at risk from sea level rise” layer in order to produce a report. You can tell if your point is in this layer if the Project in Coastal Region field in your Project Details says yes (see figure 42a). If any part of your project boundary touches the area at risk from sea level rise layer and this field says no, move your point so it intersects a part of this layer. There are several parts of the state (especially south Florida) where it is easy to find a small area just outside the area at risk from sea level rise. Activate the layer in the tool and zoom in closely to identify where to place the point.*

The point located in figure 42b below will not let you generate a SLIP report (Project in Coastal Region field will say no). The boundary of the project does intersect the area at risk from sea level rise layer (gray boundary). Move the point into the gray boundary and the Project in Coastal Region field will update to “yes”. Now you can generate a SLIP report. If none of the project area intersects the gray boundary then a SLIP report is not required.




Figure 42b: Identify project area in MapViewer




Figure 43: Generate SLIP Report Modal

On the confirmation modal, click the “Generate Report” button to generate the SLIP report for the selected project.

The report may take up to one minute to generate. The user may navigate off the project page and will be notified once the report is created.




Figure 44: Generating SLIP Report Message

Once the report is created, a notification will be displayed confirming the report creation and a link to view the report.




Figure 45: Generate SLIP Report Confirmation

The created report can also be viewed from the **Project Details** panel by clicking the “View SLIP Report” button.

The report will be sent to the Florida DEP for review. If approved, the SLIP report must be published on the SVA application site for 30 days before construction can commence. The user who created the report will receive a notification email (Appendix A.9) entailing a receipt/acknowledgement of Department approval and that it's been published to the SVA application. After the SLIP report has been published for 30 days, the user will receive an email confirming that the 30-day publication period has been completed and construction can commence (Appendix A.11). If denied, the creator of the report will be notified via email (Appendix A.10) with an explanation of the denial.

4.7 Initiate New Grant Application

From the **Project Details** panel for a selected project, you can click “Initiate New Grant Application” to open a confirmation modal to navigate to the Florida DEP Grant Application Portal.

NOTE: Grant Applications can only be initiated for projects that do NOT yet have an initiated Grant Application.




Figure 46: Submit Grant Application Modal

On the confirmation modal, click the “Go to FDEP Application Site” button to continue the grant application process.

4.8 Create Project from Critical Asset

From the SVA Map Viewer tab, while viewing the details for a selected map asset (see **3.3 Item Details**), you can choose to create a project from the selected asset.

To do this, use the “Create New Project from this Asset” button in the item details panel.




Figure 47: Item Details

You will be taken to the Create Project screen (see **4.2 Create New Project**), with the location and other metadata already prefilled.




Figure 48: Create Project from Critical Asset

Enter the relevant project details and click "Create Project" to finish the project creation flow.

When viewing the project details for the created project, you will be able to see the linked critical asset and navigate to it from the project details panel.

5 Admin

5.1 Organization Admin

This section covers the functionality of the Admin tab for administrators of any organization type.

The Admin tab can be accessed through the top navbar if you have the Administrator role in your organization.

5.1.1 All Organizations

Two of the tabs in the side navbar (Approvals and Organization Users) will be accessible to admins of every organization type. The remaining tab will only be available to certain organizations and will be described below in sections **5.1.2 Eligible Entity Organizations** and **5.1.3 Contractor Organizations**, respectively.

5.1.1.1 Approve Org Access

On the Approvals tab, with the Organization Access sub-tab active, you can see a list of users requesting access to your organization.

First name	Last name	email	Phone	Date	Actions
Brk	Demo5	bozcgalar+sva_demo6@seamgen...		8/7/2024	<button>Approve</button> <button>Deny</button>

Figure 49: Approvals Page

To approve an access request, click the “Approve” button on that row. A dialog will appear asking you to set permissions for the user.




Figure 50: Edit User Permissions Modal

Once you are satisfied with the configured permissions, click the “Save” button to complete the approval. The approved user is now added to your organization and will be informed of the approval via email (Appendix A.2).

To deny an access request, click the “Deny” button on that row. A dialog will appear allowing you to provide an optional denial message to the requesting user.




Figure 51: Deny Access Modal

Once you have finished entering your message (or decided to skip entering a message), click the “Deny” button to complete the denial. The affected user will be notified of their denial via email (Appendix A.3).

5.1.1.2 Organization Users

On the Organization users tab, you can see all users within your organization.

If you have appropriate permissions, you may also change the permissions of each user, grant/revoke administrator access to each user, or remove them from the organization entirely.

First name	Last name	Email	Phone	Administrator
Elle	Ent-Admin	slutske+sva_eligible_entity_admin@seamgen.c...		<input checked="" type="checkbox"/> Org Owner
Katie	Bee	kgielawiec+eemail@seamgen.com		<input checked="" type="checkbox"/>
Seamgen	Demo5	slutske+sva_demo5@seamgen.com		<input type="checkbox"/>

Figure 52: Organization Users Page

5.1.2 Eligible Entity Organizations

For Eligible Entity organizations, administrators will have access to the Contractor Orgs. tab on the Admin page.

5.1.2.1 View Contractor Orgs

On the Contractor Orgs. tab, with the Active sub-tab selected, you can see a list of contractor organizations that currently have access to your organization.

From here, you may also revoke a contractor organization's access (see **5.1.2.3 Remove Org**).

Contractor Organizations

Martin County

Active (4) Invite Pending (1) Access Requests (0)

Organization Full Name	Organization Short Name	Primary Admin
Scripps Institute of Oceanography	SIO2	Katie Bee
General Contractos Inc	GCI	Pete Nystrom
Seamgen Electric	SGE	Katie Bielawiec
UCSD Contractor	UCSD	Seth Lutske

Rows per page: 10 ▾ 1-4 of 4 < >

Figure 53: Contractor Organizations Page

With the Invite Pending sub-tab selected, you can see a list of contractor organizations that have been invited to access your organization but have not yet accepted the invitation. You may cancel an invite at any time from this page.

Florida Department of Environmental Protection
Statewide Vulnerability Assessment

Admin SVA Map Viewer Projects

Contractor Organizations

Martin County

Active (4) **Invite Pending (1)** Access Requests (0)

Organization Full Name	Organization Short Name	Primary Admin
Seamgen Electric	SGE	Katie Bee

Cancel Invite

Rows per page: 10 ▾ 1-1 of 1 < >

Figure 54: Contractor Organizations Page (Invite Pending Tab)

With the Access Requests sub-tab active, you can see a list of contractor organizations that are requesting access to your organization. You may approve or deny access to these organizations from this page.

Contractor Organizations

Search Organizations + Invite Organization

Martin County

Active (3) Invite Pending (1) **Access Requests (1)**

Organization Full Name	Organization Short Name	Primary Admin
UCSD Contractor	UCSD	Seamgen Demo8

Approve Deny

Rows per page: 10 ▾ 1-1 of 1 < >

Figure 55: Contractor Organizations Page (Access Requests Tab)

5.1.2.2 Invite Org

On the Contractor Orgs tab, you can use the “Invite Organization” button to send an invitation to a contractor organization to access your organization.

Contractor Organizations

Search Organizations + **Invite Organization**

Martin County

Active (3) Invite Pending (1) Access Requests (1)

Organization Full Name	Organization Short Name	Primary Admin
Scripps Institute of Oceanography	SIO2	Katie Bee
General Contractors Inc	GCI	Pete Nystrom
Seamgen Electric	SGE	Katie Bielawiec

Rows per page: 10 ▾ 1-3 of 3 < >

Figure 56: Invite Organization Button

Clicking the button will bring up a dialog allowing you to search for a contractor organization to invite.




Figure 57: Invite Contractor Organization Modal

Once you have selected a contractor organization and pressed “Continue”, you will be taken to a dialog to confirm your invitation.





Figure 58: Invite Contractor Organization Modal (Confirmation)

Clicking “Invite Organization” will send the invitation via a notification. Once accepted, the selected contractor organization will have access to your organization’s projects and views.

5.1.2.3 Remove Org

While viewing contractor orgs who currently have access to your organization, you can use the “Delete” icon button on a row to revoke access from that organization.




The screenshot shows the 'Contractor Organizations' page. The left sidebar has 'Contractor Orgs.' selected. The main table has three rows:

Organization Full Name	Organization Short Name	Primary Admin	Action
Scripps Institute of Oceanography	SIO2	Katie Bee	
General Contractos Inc	GCI	Pete Nystrom	
Seamgen Electric	SGE	Katie Bielawiec	

At the bottom, there are pagination controls: 'Rows per page: 10', '1-3 of 3', and navigation arrows.

Figure 59: Remove Contractor Organization Button

When the button is pressed, you will be shown a dialog prompting you to confirm that you would like to revoke access from the selected organization.



The modal dialog is titled 'Remove Organization Connection'. It displays the organization details:

Organization Full Name	Organization Short Name
Scripps Institute of Oceanography	SIO2

The message inside the dialog is: "All employees for this contractor organization will lose access to your organization's projects." At the bottom are 'Cancel' and a red 'Remove Connection' button.

Figure 60: Remove Organization Connection Modal

Clicking “Remove Connection” will revoke the selected organization’s access to your organization, and the primary admin of that organization will be notified of the change via the notification panel.


5.1.3 Contractor Organizations

For contractor organizations, administrators will have access to the Eligible Entity Orgs. tab on the Admin page.

5.1.3.1 View Eligible Entity Orgs

On the Eligible Entity Orgs. tab, with the Active sub-tab selected, you can see a list of Eligible Entity organizations that you currently have access to.

From here, you may also remove your own access to any of these organizations (see **5.1.3.3 Remove Org**).



The screenshot shows the 'Eligible Entity Organizations' page. At the top, there is a header with the Florida Department of Environmental Protection logo, 'Statewide Vulnerability Assessment', and navigation links for 'Admin', 'SVA Map Viewer', and 'Projects'. On the left, a sidebar has links for 'Approvals', 'Organization Users', and 'Eligible Entity Orgs.' (which is currently selected). The main content area has a title 'Eligible Entity Organizations' and a subtitle 'Scripps Institute of Oceanography'. It includes a search bar and a 'Request Access to Organization' button. Below this, there are three sub-tabs: 'Active (3)', 'Invite Pending (0)', and 'Access Requests (0)'. The 'Active' tab is selected. The table lists three organizations:

Organization Full Name	Organization Short Name	Primary Admin	Action
Miami County	MCT	Seamgen QA3	
Martin County		Katie Bee	
Florida DEP		Katie Bielawiec	

At the bottom, there are pagination controls: 'Rows per page: 10', '1-3 of 3', and navigation arrows.

Figure 61: Eligible Entity Organization Page

With the Invite Pending sub-tab selected, you can see a list of Eligible Entity organizations that have invited you to access their organization. You may accept or deny the invites to these organizations from this page.

Florida Department of Environmental Protection
Statewide Vulnerability Assessment

Admin SVA Map Viewer Projects

Approvals Organization Users Eligible Entity Orgs.

Eligible Entity Organizations

Search Organizations + Request Access to Organization

Scripps Institute of Oceanography

Active (3) Invite Pending (1) Access Requests (0)

Organization Full Name	Organization Short Name	Primary Admin
Martin County		Katie Bee

Approve Deny

Rows per page: 10 ▾ 1–1 of 1 < >

Figure 62: Eligible Entity Organizations Page (Invite Pending Tab)

With the Access Requests sub-tab selected, you can see a list of Eligible Entity organizations that your organization has requested access to. You may cancel these requests at any time from this page.

Florida Department of Environmental Protection
Statewide Vulnerability Assessment

Admin SVA Map Viewer Projects

Approvals Organization Users Eligible Entity Orgs.

Eligible Entity Organizations

Search Organizations + Request Access to Organization

Scripps Institute of Oceanography

Active (3) Invite Pending (0) Access Requests (1)

Organization Full Name	Organization Short Name	Primary Admin
SVA Demo Org	Demo	Seamgen QA3

Cancel Request

Rows per page: 10 ▾ 1–1 of 1 < >

Figure 63: Eligible Entity Organizations Page (Access Requests Tab)

5.1.3.2 Request Access

On the Eligible Entity Orgs tab, you can use the “Request Access to Organization” button to send an access request to an Eligible Entity organization.

Organization Full Name	Organization Short Name	Primary Admin
Miami County	MCT	Seamgen QA3
SVA Demo Org	Demo	Seamgen QA3
Martin County		Katie Bee
Florida DEP		Katie Bielawiec

Figure 64: Eligible Entity Organizations Page

Clicking the button will bring up a dialog allowing you to search for an eligible entity organization to request access to.

Figure 65: Request Access to Eligible Entity Organization Modal

Once you have selected an eligible entity organization and pressed “Continue”, you will be taken to a dialog to confirm your request.




Figure 66: Request Access to Organization Modal (Confirmation)

Clicking “Request Access” will send the request via the notification panel. Once accepted, you will have access to the selected Eligible Entity organization’s projects and views.

5.1.3.3 Remove Org

While viewing Eligible Entity organizations who your organization currently has access to, you can use the “Delete” icon button on a row to remove your organization’s access to them.




Figure 67: Eligible Entity Organizations Page

When the button is pressed, you will be shown a dialog prompting you to confirm that you would like to remove your access to the selected organization.




Figure 68: Remove Organization Connection Modal

Clicking “Remove Connection” will remove your access to the selected organization, and the primary admin of that organization will be notified of the change via the notification panel.

Appendix A: Email Notifications

A.1 Organization Access Requested (Employee)

Sent to: Organization Admins

Subject: Organization Access Requested

Email Body:

Hello,

#FirstName# #LastName# has requested organization access to #OrgName#. Please log into the SVA Tool to approve/deny access for this employee.

Thank you,

Florida Department of Environmental Protection

A.2 Organization Access Approved

Sent to: User Requesting Access

Subject: Organization Access Approved

Email Body:

Hello,

#FirstName# #LastName#, your organization access to #OrgName# has been approved. You can now work under #OrgName# with employee access in the SVA Tool. If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.3 Organization Access Denied

Sent to: User Requesting Access

Subject: Organization Access Denied

Email Body:

Hello,

Your organization access request was denied because: #DENIAL_REASON#. Please ensure you selected the correct organization to join. If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.4 Organization Access Requested (Contractor Relationship)

Sent to: Eligible Entity Admins

Subject: Organization Access Requested

Email Body:

Hello,

A new organization with name: #OrgName# has requested access to work with #EligibleEntityName#. Please log into the SVA Tool to approve/deny access for #OrgName#.

Thank you,

Florida Department of Environmental Protection

A.5 Organization Access Approved (Contractor Relationship)

Sent to: User Requesting Access

Subject: Organization Access Approved

Email Body:

Hello,

This email confirms your organization, #OrgName#, has been approved by a team member of #EligibleEntityName#. You now have a contractor relationship with #EligibleEntityName#. If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.6 Organization Access Denied (Contractor Relationship)

Sent to: User Requesting Access

Subject: Organization Access Denied

Email Body:

Hello,

This email is a notification that your organization, #OrgName's#, request to work with #EligibleEntityName# in the SVA application has been denied. Please ensure you selected the correct Organization to join. If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.7 Organization Access Approved (New Organization)

Sent to: User Requesting Access

Subject: Organization access Approved

Email Body:

Hello,

This email confirms your organization #OrgName# has been approved by a DEP team member. #OrgName# is now on the list of organizations available for users to join in the SVA Tool. If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.8 Organization Access Denied (New Organization)

Sent to: User Requesting Access

Subject: SVA Access Request Denied

Email Body:

Hello,

This email is to inform you that your organization #OrgName# was denied access to the SVA application by the System Administrator. If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.9 SLIP Study Approved

Sent to: User Who Submitted Report

Subject: SLIP Study Approved

Email Body:

Hello,

This email confirms that your SLIP study titled #Project Name# has been reviewed and approved: <https://prodapps.dep.state.fl.us/orcp-sva/admin/slip/#ID#>. The SLIP study will be

uploaded to the SVA Tool website. Please note the report must be published for a minimum of 30 days before construction is allowed to start. If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.10 SLIP Study Denied

Sent to: User Who Submitted Report

Subject: SLIP Study Denied

Email Body:

Hello,

This email confirms that the SLIP study titled #Project Name# you submitted has been reviewed and denied: #DENIAL_REASON# <https://prodapps.dep.state.fl.us/orcp-sva/projects/#ID#/slip/>. If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.11 SLIP Study Published for 30 Days

Sent to: User Who Submitted Report

Subject: SLIP Study Published for 30 days

Email Body:

Hello,

This email confirms that the required 30-day publication of your SLIP study titled #Project Title# has been completed. You may now commence construction. As required in Section 380.0937, Florida Statutes, the SLIP study must be maintained on the Department's website for a minimum of 10 years, which began on [date published.] The report has been uploaded to the SVA Tool website.

If you have any questions, please email Resilience@FloridaDEP.gov or call (850) 245-7600.

Thank you,

Florida Department of Environmental Protection

A.12 Invitation to Join Organization

Sent to: Contractor Admins

Subject: Invitation to Join Organization

Email Body:

Hello,

This email is a notification that #ContractorOrgName# has been invited to join #EligibleEntity#. Please log in to the SVA Tool to approve/deny the invitation.

Thank you,

Florida Department of Environmental Protection

A.13 Contractor Denied Invitation Request

Sent to: Eligible Entity User Who Sent Invitation

Subject: Contractor Denied Invitation Request

Email Body:

Hello,

This email is a notification that #ContractorOrgName# has denied joining #EligibleEntityName#. Please ensure you invited the correct Contractor Organization.

Thank you,

Florida Department of Environmental Protection

A.14 Contractor Approved Invitation Request

Sent to: Eligible Entity User Who Sent Invitation

Subject: Contractor Approved Invitation Request

Email Body:

Hello,

This email confirms that #ContractorOrgName# has approved the invitation to join #EligibleEntityName#. #ContractorOrgName# now has access to #EligibleEntityName#'s projects.

Thank you,

Florida Department of Environmental Protection